





4

Input and Mode Switch



INPUT AND MODE SWITCH
PARTS LIST

Symbol No.	Part No.	Description
DIODES (SIG = Signal, CF = Carbon Film)		
D401	070047	SIG, 75V, 10mA, 1N4148
D402	070047	SIG, 75V, 10mA, 1N4148
D403	070047	SIG, 75V, 10mA, 1N4148
D404	070047	SIG, 75V, 10mA, 1N4148
D406	070047	SIG, 75V, 10mA, 1N4148
D407	070047	SIG, 75V, 10mA, 1N4148
D408	070047	SIG, 75V, 10mA, 1N4148
D409	070047	SIG, 75V, 10mA, 1N4148
D410	070047	SIG, 75V, 10mA, 1N4148
D411	070047	SIG, 75V, 10mA, 1N4148
D412	070047	SIG, 75V, 10mA, 1N4148
D413	070047	SIG, 75V, 10mA, 1N4148
D414	070047	SIG, 75V, 10mA, 1N4148
TRANSISTORS		
Q401	132224	PNP, MPS4126
Q402	132224	PNP, MPS4126
SWITCHES		
S401	146215	Input Selector switch
S402	145215	Input Selector Switch